



T H E D I X I E G R O U P

TRUCOR™ SPC and TRUCOR™ Prime WPC Suggested underlayment and/or adhesive options when installation method calls for glue down.

Suggested Adhesives for SPC when glue down is method is needed:

- Advanced Adhesive Technologies AAT-420
- Advanced Adhesive Technologies AAT-520
 - These adhesives are recommended when gluing SPC flooring directly to wood or concrete sub-floor and/or for gluing an additional foam underlayment to the sub-floor in order to meet minimum IIC / STC sound rating requirements.

Suggested Adhesives for a glue down WPC with attached cork pad. Also, if installing an additional 1/8” CORK underlayment to increase IIC and STC Ratings:

- Mapei Eco222
- Mapei Ultrabond Eco360
- Roberts 7250

Suggested additional underlayment option when attempting to meet and/or exceed IIC and STC ratings:

Vendor: MP Global:

- QuietWalk
- QuietWalkPLUS
- QuietWalk Luxury Vinyl
- SoundBuffer
- SoundStep Luxury Vinyl

Vendor: Roberts:

- Quiet Cushion 70-180